APTC INTERNAL WATERPROOFING GUIDE

STEP 1 PRIMER | **STEP 2** BOND BREAKER | **STEP 3** REINFORCEMENT | **STEP 4** MEMBRANE

1. PREPARE THE SUBSTRATE - Choose your primer

POROUS SUBSTRATES

1



Leakproof Primer 800 - water based acrylic primer

NON POROUS eg. James Hardie Scyon



Leakproof MB2K - 2 part water based epoxy primer

2. BOND BREAKER - Choose your sealant

PROFLEX HY / PROFLEX MS

2



Proflex HY - high performance construction sealant
or
Proflex MS - advanced MS polymer based sealant

3. STRENGTHEN CRITICAL AREAS

REINFORCEMENT

3



Leakproof Bandage - for detailing and reinforcement of corners, joints & penetrations

4. MEMBRANE - Apply the membrane

APTC LEAKPROOF SBR830

4



Class III, waterborne SBR latex membrane formulated for use under tile finishes in internal and external waterproofing applications

Ideal for: Bathrooms, laundries, kitchens, wet areas & externally under tile

- Apply 2 x coats
- Brush or roller application
- 2-4 hours recoat
- Compatible with most quality Class II and III tile adhesives

For all waterproofing specifications and technical advice please contact APTC Australia 1300 394 239

APTC Australia
P | 1300 394 239 **W |** www.aptcaust.com.au
ABN 61 058 678 961